





TABLE OF CONTENTS	
1. FEATURES	02
2. SPECIFICATIONS	02
2.1 General Specifications	02
3. OPERATION	03
3.1 Front and Back Panel Description	03
3.2 Clock Adjustment	04
3.3 Temperature and Humidity Maximum (MAX) / Minimum (MIN) function	04
3.4 Alarm Adjustment	05
4. MAINTENANCE	05
4.1 Installation and Battery Change	05

1. Press the MODE button until MEM indication be shown in the display.
2. Press the UP button to change between the maximum (MAX) and minimum (MIN) value.
3. To erase the maximum (MAX) and minimum (MIN) values, select the values that will be erased and press the SET button.

#### 3.4 Alarm Adjustment

1. Press the MODE button until ALM indication be shown in the display.
2. Press the SET button to access the hour adjustment mode.
3. Press the UP button to adjust the hours. If maintain press the UP button, the speed of the adjustment of minutes will increase.
4. Press the MODE button to access the minute adjustment and press the UP button to adjust the minutes.
5. To leave this adjustment mode, press the SET button.

#### Note

Press the UP button to turn On/Off the "fix time bell" , the "on clock bell" , or the "fix time bell" , the "on clock bell" .

1

5

### 3. OPERATION

#### 3.1 Front and Back Panel Description

Refer to Figure 1 for the localization of the controls and terminals.




Figure 1

1. MODE Button: Selects the indication of the values maximum (MAX) and minimum (MIN) memorized of temperature and humidity. Also it is used for hour and alarm clock adjustment.
2. UP Button: Change between the maximum (MAX) and minimum (MIN) values, change the hour system (12h/24h) and activate the fix time bell and the on clock bell.
3. SET Button: Erase the maximum (MAX) and minimum (MIN) values, adjust the clock and the alarm clock.
4. SMP Button: Update the temperature and the humidity.

3

4

This function automatically memorize the values maximum and minimum of temperature and humidity registered by the instrument.

#### 3.3 Temperature and Humidity Maximum (MAX) / Minimum (MIN) Function

To change the hour system (12h/24h) press the UP button when the TIME indication is shown in the display.

#### Note

1. Press the MODE button until TIME indication be shown in the display.
2. Press the SET button to access the hour adjustment mode.
3. Press the UP button to adjust the hours. If keep pressed the UP button, the speed of the adjustment of minutes will increase.
4. Press the MODE button to access the minute adjustment and press the UP button to adjust the minutes.
5. To leave this adjustment mode, press the SET button.

#### 3.2 Clock Adjustment

5. °C / °F Key: Selects the unit of temperature measure between °C or °F.

2

6

Date of Issue: 08/06/2007  
Revision: 6.0.0.0

Manual specifications subject to change without notice.




Figure 2

1. Open the battery compartment located in the back of the instrument in agreement with the figure 2.
2. Remove the adhesive sealing wax of the contact.
3. Close the compartment of the battery and the instrument will be ready for use.

#### 4.1 Installation and Battery Change

When receive the instrument probably will be without an unloaded battery, effect the following procedure:

1. Open the battery compartment located in the back of the instrument in agreement with the figure 2.
2. Remove the adhesive sealing wax of the contact.
3. Close the compartment of the battery and the instrument will be ready for use.

1. Open the battery compartment located in the back of the instrument in agreement with the figure 2.
2. Remove the adhesive sealing wax of the contact.
3. Close the compartment of the battery and the instrument will be ready for use.

#### 4. MAINTENANCE

When receive the instrument probably will be without an unloaded battery, effect the following procedure:

1. Open the battery compartment located in the back of the instrument in agreement with the figure 2.
2. Remove the adhesive sealing wax of the contact.
3. Close the compartment of the battery and the instrument will be ready for use.

#### 2.1 General Specifications

Operation Environment: 0°C to +50°C, RH < 95%.

Storage Environment: -20°C to +60°C, RH < 95%.

Power Supply: 1x Battery 1.5V AAA.

Dimensions: 119(L) x 100(W) x 21(H)(mm).

Weight: Approximately 130g.

#### Temperature

Temperature Range: 0°C - +50°C (+32°F - +122°F).

Temperature Accuracy: ±1°C / ±1.8°F.

Temperature Resolution: 0.1°C or 0.1°F.

#### Humidity

Humidity Range: 20%RH - 95%RH.

Humidity Accuracy: ±8%.

Humidity Resolution: 1%.

#### 2. SPECIFICATIONS

Alarm Clock:


Selectable Format: 12h / 24h.

Memory: Register of Temperature and Humidity Maximum (MAX) and Minimum (MIN).

Temperature Indication: °C or °F.

Simultaneous Indication: Temperature, Humidity, Hour.


### THERMO-HYGROMETER WITH CLOCK



\*Only illustrative image. Imagen meramente ilustrativa.  
Imagem meramente ilustrativa.

### INSTRUCTIONS MANUAL

### THERMO-HYGROMETER WITH CLOCK



\*Only illustrative image. Imagen meramente ilustrativa.  
Imagem meramente ilustrativa.

### INSTRUCTIONS MANUAL